

IT-DUMPS Q&A

Accurate study guides, High passing rate!
IT-dumps provides update free of charge in one year!

Exam : **D-PEMX-DY-23**

Title : Dell PowerEdge MX
Modular Deploy 2023 Exam

Version : DEMO

1.What is a valid option when resetting iDRAC to factory defaults?

- A. Preserve user and network settings
- B. Preserve network and storage settings
- C. Preserve identity and network settings
- D. Preserve storage and user settings

Answer: A

2.Which ports will be active in an MX9116n FSE if there are dual-port NICs in all the server sleds?

- A. even-numbered server-facing ports
- B. server-facing ports 9–16
- C. odd-numbered server-facing ports
- D. server-facing ports 1–8

Answer: C

3.What type of connection is used by QuickSync 2?

- A. Bluetooth
- B. NFC
- C. QuickAssist
- D. LTE

Answer: A

4.A network administrator must implement a 100 GbE network in their MX7000 chassis group.

Which two components satisfy this requirement?

(Select 2)

- A. Z9432F-ON
- B. MX7116n
- C. Z9332F-ON
- D. MX9116n
- E. MX8116n

Answer: DE

5.Why is the backup lead configuration important in an MCM Group?

- A. The configuration allows sharing of the lead chassis IOMs and Management Module databases.
- B. The backup lead chassis facilitates management of systems when the existing lead chassis fails.
- C. The backup chassis is promoted automatically if the lead chassis fails.
- D. This configuration allows configuration changes from the backup chassis.

Answer: B